

ECD Disassemble and Recycling Instructions

Brentwood

Upholstered Seat With Mesh Back



Scrap Rate
>.002

Take off the **Base** from the **Cylinder** by tapping the edge of the **Cylinder** with a hammer while pulling on the **Base**

Take off the **Cylinder** from the **Mechanism** by turning the **Cylinder** using the **Pipe Wrench**

Unscrew the **Back** from the **Mechanism** with a **3/16 Allen Wrench**

Unscrew the **Back Frame** with a **1/8 Allen Wrench**
Tear off Mesh and Discard

Unscrew the **Mechanism** from the **Seat** with a **#3 Phillips bit**

Unscrew the **Set Screw** from the **In/Out Bracket** with a **3/16 Allen Wrench**

Unscrew the **Arm Pad** from the **Arm Mechanism** with a **#3 Phillip Bit**
Discard Arm Pad

Unscrew the **IN/OUT Bracket** from the **Seat** with a **#3 Philips bit**

Cut off **Fabric** from the **Seat Foam**
Discard Fabric

Peel the **Foam** off the **Seat Plywood**
Discard Plywood