


Disassembly and Recycling Instructions

Models: Multipurpose chairs with and without upholstery DELTA□

Time per chair: 12 minutes. No special training or skills needed.







- 1. Pry outer back away from back cushion. If outside back is plastic, recycle
- 2. Remove back from metal back support. Discard upholstered or wood backs. Recycle if plastic.
- 3. Remove arms. Unscrew if fasteners visible. Knock out of sockets with a hammer if no fasteners visible. Discard arms.
- 4. Unscrew seat trim from bottom of seat. Recycle seat trim.
- 5. Unscrew seat from chair frame. Discard upholstered or wood seats. Recycle plastic seats.
- 6. Recycle steel frame.

