


CALPIA Disassembly Instructions for Stanford

****Items are listed in suggested order of disassembly - Estimated time required - 90 minutes**

| STEP | DESCRIPTION | QTY | MATERIAL(S) |  | TOOL | PROCEDURE |
|------|--------------------|-----|--------------------------------------|---|------|--|
| 1 | Frame Brackets | 4 | Steel | Y | A, D | Remove bolts holding steel brackets on sofa front rail and back rail using screwdriver |
| 2 | Liner | 3 | Fabric | Y | E,F | Remove the liner on the bottom of the sofa seat deck with knife and pliers |
| 3 | Webbing | 3 | Webbing | Y | E,F | Remove the webbing on the bottom of the sofa seat deck with knife and pliers |
| 4 | Legs | 4 | Aluminum | Y | A | Remove aluminum legs from bottom of arm panels by hand or with screwdriver |
| 5 | Arm | 2 | Plywood, OSB and Hardwood and steel* | Y | E, F | Cut upholstery from arms using knife and remove staples using pliers |
| 6 | Arm Foam | 1 | Polyurethane Foam | Y | E | Cut or steam seat foam from plywood arm frame on all sides |
| 7 | Steel Pins | 6 | Steel | Y | A, D | Pry up OSB panel and remove steel pins |
| 8 | Front Rail | 1 | Plywood | Y | E, F | Cut upholstery from front rail using knife and remove staples using pliers |
| 9 | Front Rail Foam | 2 | Polyurethane Foam | Y | E | Cut or steam front rail foam from plywood front rail |
| 10 | Back Rail | 1 | Plywood | Y | E, F | Cut upholstery from back rail using knife and remove staples using pliers |
| 11 | Back Rail Foam | 2 | Polyurethane Foam | Y | E | Cut or steam back rail foam from plywood front rail |
| 12 | Seat and Back Foam | 6 | Polyurethane Foam | Y | E | Remove cushion cover from foam by unzipping or use knife |

* part is comprised of co-mingled materials. Contact your recycling facility

Caution

Proper safety equipment should be worn when attempting to disassemble any Nightingale product. Dependent on state of wear, products may have exposed sharp edges. Nightingale accepts no responsibility for any damage, accident or injury which may occur during disassembly. For further assistance, please contact Customer Service at Nightingale 1-800-363-8954



A. Screwdriver



B. Wrench



C. Allen Key



D. Hammer



E. Knife



F. Pliers

