

CAD-DRAWING
 THIS DRAWING WAS CREATED ON A COMPUTER AIDED DESIGN (CAD) SYSTEM. TO INSURE THE INTEGRITY OF THE DATA BASE, ALL CHANGES/ REVISIONS MUST BE MADE ON THE CAD SYSTEM.

REVISION	DATE
A	11/21/2019

TOOLS REQUIRED:

-  FLAT SCREWDRIVER
-  PHILLIPS SCREWDRIVER
-  PRY BAR
-  ADJUSTABLE PLIERS
-  RUBBER Mallet
-  UTILITY KNIFE
-  PUTTY KNIFE
-  PERSONAL PROTECTIVE EQUIPMENT (PPE)

MATERIAL TYPE:


- ① STEEL
- ② ALUMINUM
- ③ FABRIC
- ④ PLASTIC
- ⑤ GLASS
- ⑥ FIBERGLASS
- ⑦ FIBERBOARD
- ⑧ WOOD

PROCEDURE:

- 1) UNSCREW BOTH ARMS, BACK, FRONT & BACK RAILS FROM SEAT.
- 2) REMOVE SEAT FRAMES FROM SEAT FOAM
- 3) REMOVE ALL CASTERS & METAL FASTENERS. SORT BY MATERIAL TYPE.
- 4) REMOVE FOAM/FABRIC FROM WOOD.

GENERAL NOTES:

- 1) DISASSEMBLY TIME 20-25 MINUTES
- 2) THIS PROCEDURE ASSUMES BASIC FAMILIARITY WITH HAND TOOLS AND FURNITURE TERMINOLOGY: NO SPECIALIZED TRAINING IS REQUIRED.
- 3) ALL MATERIAL REMOVED AND DISASSEMBLED SHALL BE SORTED AND SEGREGATED WITH LIKE MATERIALS AND DISPOSED OF OR RECYCLED ACCORDING TO RECYCLING AVAILABILITY OR WASTE ACCEPTANCE.
- 4) FOR ITEMS TO BE RECYCLED, REFER TO CALPIA WEBSITE AT WWW.CALPIA.CA.GOV.



CALPIA STATE OF CALIFORNIA, PRISON INDUSTRY AUTHORITY 580 EAST NATOMA STREET, FOLSOM, CALIFORNIA, 95630			
CONFERENCE CHAIR DISASSEMBLY INSTRUCTIONS AND RECYCLING CONTENT			
SIZE	SCALE	DWG NO.	
D	NTS	624600-DR	
DRAWN BY:	DATE:		
R.MARIN	11/21/2019		

NOTE: THIS DRAWING IS PROPRIETARY INFORMATION OF THE PRISON INDUSTRY AUTHORITY AND IS NOT TO BE DISCLOSED IN PART OR AS A WHOLE WITHOUT PRIOR WRITTEN CONSENT AND PERMISSION OF THE PRISON INDUSTRY AUTHORITY